



SEMPELL

Attention

The safety of lives and property often depends on the proper operation of the pressure relief valves. Consequently, the valves should be kept clean and should be periodically tested and reconditioned to make sure they function properly.



WARNING

Suitability of the material and product for the use contemplated by the buyer is the sole responsibility of the buyer. Also storage, installation and proper use and application are the sole responsibility of the purchaser. Tyco Valves & Controls disclaims any and all liability arising out of same.

Any installation, maintenance, adjustment, repair and testing performed on pressure relief valves should be done in accordance with the requirements of all applicable Codes and Standards under which those performing such work should maintain proper authorization through appropriate governing authorities.

No repair, assembly and test work done by other than Tyco Valves & Controls shall be covered by the warranty extended by Tyco to its customers. You assume full responsibility for your work. In maintaining and repairing Tyco products you should use only parts manufactured by Tyco Valves & Controls. Call your nearest TV&C regional sales office or representative for a Tyco service engineer should you wish assistance with your field needs.

Table of Contents

1. Introduction

2. Storage and Handling

3. Installation

Care in Handling
Inspection
Inlet Piping
Outlet Piping

4. Hydrostatic Pressure Tests

Hydrostatic Test of Vessel or System
Hydrostatic Test of Outlet System

5. Setting, Testing and Adjustments

New Valves
Reconditioned Valves
Valves Removed from Service
The Test Bench
Test Fluids
Valve Operation
Set Pressure Changes
Set Pressure Adjustment
Nozzle Ring Settings

- Style ACL/ABL

Cold Differential Test Pressure Adjustments

- Temperature Correction
- Back Pressure Correction

Seat Leakage Tests

- Metal-to-Metal Seated Valves
- Soft Seated Valves

6. Valve Maintenance

Visual Inspection and Neutralizing
Disassembly
Cleaning
Inspection
Reconditioning of Valve Seats
Lapping Procedures

- Lapping Blocks
- Lapping Compounds
- Machining of Nozzle Seats
- Machining of Disc Insert Seats

Assembly
Assembly of Cap and Lifting Lever Devices
Soft Seat Construction

7. Style Variations

8. Service Records

9. Spare Parts

10. Trouble Shooting Pressure Relief Valves


Seat Leakage

- Seats Damaged by Foreign Matter
- Distortion From Piping Strains
- Operating Pressure too close to Set Pressure
- Chatter
- Incorrectly Adjusting Lifting Gear
- Other Causes of Seat Leakage
- Corrosion

11. Tyco Valves & Controls' Field Services and Repair Programs

Ordering Information

Figure 1



Parts list

No.	Part Name	Notes	No.	Part Name	Notes
1	Body		17	Spindle Cotter Pin	1 (L-T orifice)
2	Nozzle		18	Spring	3
3	Nozzle Ring	3	19	Spring Washers	3
4	Set screw	3, except P-T Orifice ACL/ABL	20	Bonnet	
4A	Set Screw	3, (M-T Orifice)	21	Bonnet Stud	
4B	Set Screw Rod	3, (M-T Orifice)	22	Bonnet Stud Nut	
4C	Set Screw Pin	3, (M-T Orifice)	24	Adjusting Bolt	
5	Disc Holder	2	25	Adjusting Bolt Nut	
6A	Bellows Tailpiece	2	26	Pipe Plug	
6B	Bellows	2	27	Set Screw Gasket	1
6C	Bellows Flange	2	28	Guide Gasket	2
8	Disc Insert	1	29	Tailpiece Gasket	1
9	Retention Clip	1	34	Seal & Wire	
10	O-Ring	1	35	Seal Clip	
11	O-Ring Retainer	2	36	Nameplate	
12	Retainer Screw(s)	2	40	Screwed Cap	
13	Nozzle Ring Lockscrew	P-T Orifice ACL/ABL	41	Cap Gasket	1
14	Set Screw Plug	P-T Orifice ACL/ABL (not shown)		Gasket Kit	1,4
15	Guide	3	42	Test Gag/Plug (Plug only shown)	
16	Spindle	3	43	Test Gag plug gasket	1

Notes

- Consumable Spare Parts: Valve parts which should be replaced as part of any disassembly, and discs and disc inserts which must be replaced if seats are damaged.
- Repair Spare Parts: Valve parts exposed to wear and/or corrosion during normal operation. They are in fluid flow paths and may require replacement as part of any repair.
- Insurance Spare Parts: Valve parts exposed to process or environmental wear and/or corrosion and may require replacement as part of a major repair.
Tyco Valves & Controls recommends that sufficient inventory of spare parts be maintained to support process requirements.
Always be sure to use genuine Tyco parts to ensure continued product performance and warranty.
- Contains complete set of gaskets for all style of valves

		SIZE STYLE ID2 AC-15-J	
SHOP NO.	61300000E	SET PRESS. PSI	100
SER. NO.	A000123	BACK PRESS. PSI	10
CAP	245 SCFM AT 60F	CDTP PSI	91
		TC PSI	1
		OVER PRESS.	10%

Figure 2
Sample nameplate

Ordering Spare Parts

When ordering spare parts, the valve size, style and assembly number and/or serial number should be given together with set pressure, part name and reference number from page 2. The valve serial number is shown on the valve nameplate. Spare parts may be ordered from any Tyco Valves & Controls Regional Sales Office or Representative.

Safety Precautions

Proper handling, storage, installation, maintenance and operation is essential to the safe and reliable functioning of any pressure relief product.

Precautionary statements in the form of warnings, cautions and notes are used throughout this instruction to emphasize important and critical factors where applicable.

Examples:



WARNING: An operating procedure or practice which if not strictly observed may result in injury to personnel or loss of life.



CAUTION: An operating procedure or practice which if not strictly observed may result in damage to or destruction of equipment.

These precautionary statements are by no means exhaustive.

Tyco Valves & Controls cannot be expected to know, evaluate, and advise customers of all the possible applications and operating conditions for its products or of the possible hazardous consequences which may result from the misapplication or misuse of such products.

Consequently, the improper handling, storage, installation, use or maintenance of any Tyco Valves & Controls Product by a non Tyco Valves & Controls employee may void any Tyco Valves & Controls guarantees or warranties with respect to such Product.

All personnel working with Tyco Valves & Controls products should be adequately trained and thoroughly familiar with the contents of the appropriate instruction manual(s).

Tyco Valves & Controls cannot evaluate all conditions in which the products may be used.

However, Tyco Valves & Controls offers the following general safety suggestions:

- Never subject valves to sharp impact loads.
Rough handling (striking, bumping, dropping, etc.) may alter the pressure setting, deform valve parts and adversely affect seat tightness and valve performance. Striking a valve which is under pressure can cause premature actuation.
- Always lower the system pressure to the pressure level specified in the instruction before making any adjustment to the valve. Furthermore, always install a proper test rod to gag an installed valve before making any ring adjustments on the valve.
- Ear and eye protection should be used when working on a valve which has pressure.
- Never stand in front of the discharge outlet of a pressure relief valve which is under pressure.
- Always stand to the side of and at a safe distance from the valve discharge and use extreme care when observing a valve for leakage.

The above precautions and suggestions are by no means exhaustive and the user should always approach and use any pressure relief valve with great care.

Operation, Installation and Safety Instructions are available at www.tycovalves.com or from your local Tyco Valves & Controls regional sales office or representative.

Installation and Maintenance Instructions

Sempell Series "A" Safety Valves

1. Introduction

Sempell Series "A" pressure relief valves have been selected for installation because of their performance features, reliability and ease of maintenance.

Adherence to the installation and maintenance procedures specified herein will provide the utmost in safety, a minimum of maintenance, and a long service life. Sempell Series "A" Valves are manufactured in accordance with the requirements of Section VIII Pressure Vessels, ASME Boiler and Pressure Vessel Code. Type AC is a conventional closed bonnet valve. Style AB has a balanced bellows for minimizing the effect of back pressure.

ACL/ABL is a high performance valve designed specifically for liquid service. The ACL/ABL features patented contoured liquid trim in a standard Series "A" envelope.

2. Storage and Handling

Valves are often on hand at the job site months before they are installed. Unless properly stored and protected, valve performance may be adversely affected.

Rough handling and dirt may damage or cause misalignment of the valve parts. It is recommended that the valves be left in their original shipping containers and that they be stored in a warehouse or at a minimum on a dry surface with a protective covering until they are used.

3. Installation

Care in Handling

Pressure relief valves must be handled carefully and never subjected to sharp impact loads. They should not be struck, bumped or dropped. Rough handling may alter the pressure setting, deform valve parts and adversely affect seat tightness and valve performance.

When it is necessary to use a hoist, the chain or sling should be placed around the valve body and bonnet in a manner that will ensure that the valve is in a vertical position to facilitate installation. The valve should never be lifted or handled using the lifting lever.

Inlet and outlet protectors should remain in place until the valve is ready to be installed on the system.

Inspection

Pressure relief valves should be visually inspected before they are installed to ensure that no damage has occurred during shipment or while in storage.

All protective material, sealing plugs and any extraneous material inside the valve body or nozzle must be removed.

The valve nameplate and other identifying tags should be checked to ensure that the particular valve is being installed at the location for which it was intended.

The valve seals protecting the spring setting and ring adjustments should be intact. If seals are not intact, the valve should be inspected, tested and seals properly installed before use.

Inlet Piping

Pressure relief valves should be mounted vertically in an upright position either directly on a nozzle from the pressure vessel or on a short connecting fitting that provides direct and unobstructed flow between the vessel and the valve. Installing a pressure relief valve in other than this recommended position might adversely affect its operation. Where rounded or beveled approaches cannot be provided ahead of the valve it is recommended that one size larger nozzle or fitting be used. A valve should never be installed on a fitting having a smaller inside diameter than the inlet connection of the valve.

Inlet piping (nozzles) must be designed to withstand the total resultant forces due to the valve discharging at the maximum accumulated pressure and the expected piping loads. The magnitudes of the bending moment exerted on the inlet piping will depend on the configuration and method of supporting the outlet piping.

Many valves are damaged when first placed in service because of failure to clean the connections properly when installed. Both the valve inlet and the vessel and/or line on which the valve is mounted must be thoroughly cleaned of all foreign material. The inlet connection bolts or studs should be drawn down evenly to avoid straining the valve body with possible distortion of the nozzle flange or base.




Figure 3
Recommended installation-
discharging to atmosphere

Outlet Piping

Outlet piping should be simple and direct. Where possible, for non-hazardous fluids, a short discharge pipe or vertical riser connected through a long radius elbow venting directly to atmosphere is recommended. Such discharge piping should be at least the same size as the valve outlet.

All discharge piping should be run as direct as is practicable to the point of final release for disposal. Valve effluent must discharge to a safe disposal area.

Where discharge piping is long, due consideration shall be given to the use of long radius elbows, and the reduction of excessive line strains through the use of expansion joints and proper means of support to minimize line sway and vibration under operating conditions. Adequate drainage is required to prevent corrosive media from collecting in the discharge side of the pressure relief valve. When required, low point drains shall be provided in the discharge pipe. Particular care must be observed to ensure that the drains are directed or piped to a safe disposal area.

In installations where the pressure relief valve discharges into a closed system, care must be taken to ensure that built up and superimposed back pressure has been properly calculated, specified, and accounted for when sizing and selecting the valve.

Where built up back pressure is expected to exceed 10% of set pressure or if superimposed back pressure is variable, a bellows valve is required.

4. Hydrostatic Pressure Tests

Hydrostatic Test of Vessel or System

When a pressure vessel or system is to be hydrostatically tested, it is recommended that the pressure relief valve be removed and a blank flange be installed in its place. This practice precludes the possibility of any damage to the pressure relief valve. Bent spindles and damaged valve seats are problems that can be caused by improper hydrostatic test procedures. Blank flanges must be removed and the pressure relief valve reinstalled before the vessel is placed in service.

When the hydrostatic test must be performed with the valve in place, a test gag may be used. Sempell Series "A" valves are designed to accommodate test gags for use with each type of cap. In the case of the Type C cap with lifting lever, the lifting lever assembly must be replaced with a hydrostatic test cap and test rod prior to hydrostatic testing. When test rods are used, care must be exercised to prevent overtightening that could damage the valve spindle and valve seats. A test rod which is hand tight will generally provide sufficient force to hold the valve closed. After the hydrostatic test, the test rod (gag) must be removed and replaced by either a cap plug or a cap not fitted with a test rod.

Hydrostatic Test of Outlet System

When a hydrostatic test must be conducted on the outlet piping system, with the valve in place, special consideration must be given not to exceed the design pressure limits of the downstream side of the pressure relief valve. The outlet side of a pressure relief valve is known as the secondary pressure zone. This zone is normally designed to a lower pressure rating than the inlet and frequently is designed to a lower pressure rating than the outlet flange. This is particularly true in the case of balanced bellows designs and in the larger valve sizes. Consult Sempell products specifications for the back pressure design limits of the Series "A" valves.

5. Setting, Testing and Adjustments

New Valves

Each Sempell pressure relief valve is carefully set and tested at the factory prior to shipment. However, it is good practice to inspect the valve prior to installation. This inspection determines any damage which may have occurred due to rough handling in transit or storage and initiates appropriate service records.

Reconditioned Valves

Valves which have not been in service for extended periods due to plant shutdown or long term storage, or valves which have been repaired or reconditioned, should also be tested before being put into operation.

Valves Removed From Service

Valves being removed from service should be tested on a shop test bench before being disassembled to determine the set pressure and seat tightness. This is an important phase of the maintenance routine and the test results should be recorded for review and determination of necessary corrective action.

The "as received from service" condition of a pressure relief valve is a most useful tool in establishing the proper time interval between inspections.



CAUTION: Improper testing may cause valve damage and seat leakage.

The Test Bench

The quality and condition of the shop test bench is paramount to obtaining proper test results. The test bench must be free of leaks and the test fluid must be clean. Solids or other foreign material in the test medium will damage the seating surfaces of the pressure relief valve being tested.

The test pressure gage must be calibrated and have a range proper to the pressure level of the valve setting. Set pressure should fall within the middle third of the dial range of the test gage. The test bench provides an accurate and convenient facility for determining valve set pressure and seat tightness. It does not duplicate all of the field conditions to which a pressure relief valve will be exposed while in service. It is not practical to attempt to measure relieving capacity or blowdown using a test bench.

Test Fluids - Set Pressure Test

The Test Fluid should be air or nitrogen for valves used on gas and vapor service and water for valves used on liquid service. Valves for steam service should be tested on steam. It may be necessary to make a correction to the adjusted set pressure to compensate for the difference in temperature of the test fluids(see appropriate instruction).

Valve Operation

Sempell Series "A" valves intended for compressible fluid service and tested with air or steam will open with a sharp clear popping action at the set point. Valves for liquid service tested with water are considered open when there is a continuous unbroken stream of liquid flowing from the valve.

Set Pressure Changes

Set pressure changes beyond the Sempell specified spring range will necessitate a change in the valve spring assembly consisting of the spring and two fitted spring washers. The new spring and washers must be obtained from Sempell and the valve must be reset and the nameplate restamped by an authorized valve repair facility.

Set Pressure Adjustment

Before making any adjustments reduce the pressure under the valve seat to at least 10% below the stamped opening pressure. This will prevent seat damage due to turning of the disc on the nozzle seat and minimize the chance of an inadvertent valve opening. A strong (high) ring position is necessary to obtain a good clean popping action of the valve on air or gas with the limited volume available on the test bench.

- a. (Not required for testing on liquid.) Remove the nozzle ring set screw and raise the nozzle ring until it touches the disc holder, then back it down two (2) notches. Exercise care in counting the number of notches moved so that the ring can be returned to its proper position following testing.
Moving the notches on the nozzle ring to the left will lower the nozzle ring.
Replace the nozzle ring set screw before each set pressure test. The set screw must engage one of the ring notches, being careful that it does not bear on the top of a tooth.
- b. Remove the cap or lifting lever following the instruction for valve disassembly. (See paragraph 6)
- c. Loosen the adjusting bolt nut and turn the adjusting bolt clockwise to increase set pressure or counterclockwise to reduce set pressure.
- d. Retighten the adjusting bolt nut following each adjustment.
- e. Two or three consecutive valve openings at the same pressure are necessary to accurately verify the opening pressure.
- f. Once the set pressure has been established, lower the nozzle ring to the installed ring position as indicated in Table 1 and replace the nozzle ring set screw as described above. Seal wire the adjusting bolt and adjusting ring set screw with identifying seals.

Nozzle Ring Settings

The nozzle ring adjustment is made at the factory and resetting in service is seldom necessary.

Should it be necessary to change blowdown or reduce valve simmer, the nozzle ring may be adjusted as follows: (See the next paragraph for P, Q, R and T Orifice Style ACL/ABL)

- a) Remove the nozzle ring set screw and insert a screwdriver to engage the ring notches.
- b) Turning the ring to the right raises the ring, thereby increasing blowdown. Turning the ring to the left lowers the ring, thereby decreasing the blowdown.
- c) Do not lower the nozzle ring to the point where the valve begins to have excessive simmer. Raising of the ring will reduce simmer.
- d) The nozzle ring should not be moved more than two notches before retesting. When making adjustments, always keep count of the number of notches and the direction in which the nozzle ring is moved. This will permit returning to the original setting in case of error.



CAUTION: Should any adjustments be made while the valve is installed on a pressurized system, the valve should be gagged while ring adjustments are made.

• *Style ACL/ABL*

The Style ACL/ABL in the P, Q, R and T Orifice sizes is preset at the factory and cannot be externally adjusted in the field, since the special contoured skirt on the disc holder prevents engagement of the set screw with the nozzle ring. As a result the nozzle ring is not slotted and is held in place by three set screws. The position of the nozzle ring must be set prior to valve assembly as follows:

- a. Screw the nozzle ring (3) on to the nozzle. The top of the nozzle ring should be below the nozzle seating surface.
- b. Install the disc insert retention clip (9) onto the disc insert. Assemble the disc insert (8) and disc holder (5). The disc insert should snap into place using hand force only.
- c. Lower the disc holder and disc insert carefully onto the nozzle.
- d. Reach through the valve body outlet and turn the nozzle ring until it lightly touches the disc holder. This is the highest lock position.
- e. Carefully remove the disc holder and disc insert from the valve.
- f. Lower the nozzle ring (turn to the left) the total number of revolutions shown in Table 2.
- g. Carefully tighten each of the set screws on the nozzle ring to hold the ring in position.

Table 2

ACL/ABL Orifice Size	Nozzle Ring Setting Total revolutions below highest lock position
P and Q	3/4 Revolution
R and T	1 Revolution

Table 1

Service	Orifice size	Nozzle ring setting (Below Highest Lock Position)
Styles AC/AB Pressure Relief Valve Recommended Nozzle Ring Settings		
Vapor & Gases	D through J	-5
	K through N	-10
	P through T	-15
Liquids	D through G	-5
	H through K	-10
	L through N	-20
	P through T	-30

Styles ACL/ABL Pressure Relief Valve Recommended Nozzle Ring Settings

Liquids & Gases	D, E, and F	-3
	G, H, and J	-5
	K and L	-10
	M and N	-15
	P and Q	(See table 2)
	R and T	(See table 2)

Minus sign: indicates number of ring notches below starting position of nozzle ring which is the highest position with the valve closed (contact with disc holder)

Table 3

Operating	
Temperature	% Excess Pressure
0-150°F	None
151-600°F	1%
601-800°F	2%
801-1000°F	3%

Table 4 - (AC Style Only)

Orifice Size	Saturated Steam Set Pressure (max)
D, E, F, G, H, J, K, L	1500 psig
M	1100 psig
N, P	1000 psig
Q	600 psig
R, T, T ₂	300 psig

Table 5 - Saturated Steam Service

Air Set Pressure Correction Factors at Ambient Temperature

Set Pressure (psig)	% Increase in Spring Set Pressure
15-400	3%
401-1000	4%
1001-1500	5%

Cold Differential Test Pressure Adjustments

When a pressure relief valve is on a test bench at room temperature and atmospheric pressure, and is to be installed on a system operating at a higher temperature and/or a higher back pressure, a compensating adjustment is necessary. The test pressure required to have the valve open at the desired set pressure under actual service conditions is known as the cold differential test pressure.

• *Temperature Correction*

When a Sempell Style AC/ABL valve is set on air or water at room temperature and then used at a higher service temperature, the test pressure shall be corrected to exceed the set pressure using the temperature correction shown in Table 3.

Note: this table is not applicable to steam service valves.

• *Back Pressure Correction*

Conventional valves without balancing bellows set with atmospheric pressure at the outlet and intended for use under elevated constant back pressure conditions shall be adjusted so that the test pressure is equal to the set pressure minus the expected back pressure. See example below:

Set Pressure	100 PSI
Constant Back Pressure	10 PSI
Cold Differential Test Pressure	90 PSI

In all instances, the spring should be selected based on the cold differential test pressure; in the example above, 90 PSI. See sample nameplate on page 3 which shows how temperature and back pressure is indicated.

Saturated Steam Correction Factors

Sempell Style AC pressure relief valves that are used for saturated steam service and are within the set pressure limits established in Table 4 may be set on air at ambient temperature, provided the correction factors in Table 5 are applied to the valve set pressure.

Seat Leakage Tests

Ambiguous terms such as "bubble tight", "drop tight", "zero leakage" and "commercial tightness" are sometimes used to describe seat tightness. These terms, however, lack uniform definition and true practical meaning.

• Test Procedure

API Standard 527 provides a standard for "commercial" tightness and has been adopted by industry and users in order to clarify testing methods and tightness criteria. This standard applies to flanged inlet nozzle type pressure relief valves.

• Test Apparatus

A typical test arrangement for determining seat tightness for pressure relief valves per API Standard 527 is shown in Figure 4. Leakage is measured using a 5/16 in. OD tube with 0.035 in. wall. The tube end is cut square and smooth, is parallel to and 1/2 inch below the surface of the water. A snap-on type test clamp shown in Figure 5 is available.

• Procedure

With the valve mounted vertically, the leakage rate in bubbles per minute shall be determined with pressure at the pressure relief valve inlet raised up to and held at 90 percent of the set pressure (or cold differential test pressure - CDTP) immediately after popping. This applies except for valves set at 50 psig or below, in which case the pressure shall be held at 5 psig below the set pressure immediately after popping. The test pressure shall be applied for a minimum of one minute for valves of inlet sizes through 2"; two minutes for sizes 2 1/2", 3" and 4"; five minutes for sizes 6" and 8". Air (or nitrogen) at approximately ambient temperature shall be used as the pressure medium.

• Tightness Standard

- Metal-to-Metal Seated Valves. The leakage rate in bubbles per minute shall be observed for at least one minute and shall not exceed the values indicated in table 6 below.
- Soft Seated Valves. For soft seated valves there shall be no leakage for one minute (zero bubbles for one minute).

Table 6 - Maximum seat leakage rate - Metal seated pressure relief valves

Set Pressure PSIG (BarG)	Effective Orifice Sizes 0.307 In ² and Smaller			Effective Orifice Sizes Larger than 0.307 In ²		
	Max. Bubbles per Minute	Approximate Leakage Rate Per 24 Hours		Max. Bubbles per Minute	Approximate Leakage Rate Per 24 Hours	
		Standard Cubic Feet	Standard Cubic Meters		Standard Cubic Feet	Standard Cubic Meters
15-1000 (1.03-68.9)	40	0,6	0,017	20	0,3	0,0085
1500 (103.4)	60	0,9	0,026	30	0,45	0,013
2000 (137.9)	80	1,2	0,034	40	0,6	0,017
2500 (172.4)	100	1,5	0,043	50	0,75	0,021
3000 (206.8)	100	1,5	0,043	60	0,9	0,026
4000 (275.8)	100	1,5	0,043	80	1,2	0,034
5000 (344.8)	100	1,5	0,043	100	1,5	0,043
6000 (413.7)	100	1,5	0,043	100	1,5	0,043

• Sempell Seat Tightness Standard-Liquid Service Valves (Style ACL/ABL)

Crosby liquid service pressure relief valves are checked for seat tightness by a quantitative seat leakage test.

All of the test fluid passing through an assembled valve is collected and measured per the following test procedure:

- The inlet pressure is adjusted to a test pressure which is 90% of the Cold Differential Test Pressure.
Valves set below 50 psig are tested at 5 psig below the cold differential test pressure.
- The test pressure is maintained for a period of not less than ten minutes.

• Allowable Leak Rate

The maximum allowable leakage rate should not exceed 10 cubic centimeters per hour per inch of diameter of nominal valve inlet size. For nominal valve sizes of 1 inch or less, the leakage rate shall not exceed 10 cubic centimeters per hour. For soft seated valves there shall be no leakage for one minute.

• Soft Seated Valves

For exceptional seat tightness, Sempell offers an O-ring soft seat design. Refer to Figure 13 on page 15.

The Sempell soft seat design will provide a valve that has no visible leakage at a test pressure of 90 percent of the set pressure or cold differential test pressure. Soft seated valves are tested using the same test procedure used for metal-to-metal seated valves.

Figure 4 - Typical test arrangement






Figure 5 - Seat leak apparatus for 150 & 300 lb. outlets 1 inch through 10 inch sizes




CAUTION: Valves in hazardous fluid service and any other materials classified as dangerous must be neutralized immediately after removal from service.

Table 7 - Series "A" disc insert threaded hole sizes

Orifice Size	Thread Size
D & E	# 10-24 UNC
F, G H	1/4 - 20 UNC
J, K, L	1/4 - 20 UNC
M, N, P, Q, R, T	3/8 - 16 UNC



Remove disc insert by pulling on bolt



Remove disc insert by turning nut with wrench

Figure 6




Figure 7
Remove disc insert by pulling on bolt

6. Valve Maintenance

Visual Inspection and Neutralizing

A visual inspection shall be made when valves are first removed from service. The presence of deposits or corrosion products in the valve and in the piping should be recorded and valves should be cleaned to the extent possible prior to disassembly. Check the condition of external surfaces for any indication of corrosive atmospheric attack or evidence of mechanical damage.

Disassembly

Sempell Series "A" Series 8000 valves should be disassembled as described below. Parts identification may be found in Figure 1 on page 2. The parts from each valve should be properly marked and segregated to keep them separate from parts used in other valves.

- Remove the cap (40) and cap gasket (41). If the valve has a lifting lever device follow the instructions on pages 15.
- Remove the nozzle ring set screw (4) and set screw gasket (27).
Record the position of the nozzle ring (3) with respect to the disc holder (5) by counting the number of notches required to raise the ring until it just touches the disc holder. This information will be needed again when reassembling the valve. (Measure the revolutions for P, Q, R and T Orifice Style ACL/ABL. See Table 2)
- Loosen the adjusting bolt nut (25). Before releasing the spring load, make note of the depth of the adjusting bolt in the bonnet and count the number of turns required to remove the spring load. This information will help when reassembling the valve to its approximate original setting.
- Release all of the spring load by rotating the adjusting bolt (24) in a counterclockwise direction.
- Remove the bonnet stud nuts (22).
- Lift the bonnet (20) straight up to clear the spindle (16) and valve spring (18). Exercise care when lifting the bonnet as the spring and spindle will then be free to fall aside.
- The spring and spring washers (19) can now be lifted off the spindle (16). The spring and spring washers are fitted together and must be kept together as a subassembly. Spring washers are not interchangeable between ends of the spring.
- Remove the spindle, guide (15), disc holder and disc insert (8). For balanced bellows valves (Style AB/ABL) special care must be taken not to damage the bellows subassembly (6).
If parts are difficult to remove, due to the presence of corrosive or foreign materials, soaking in a suitable solvent may be required.
- Remove the spindle from the disc holder.
- Lift the guide off the disc holder.
- Disc Insert Removal

- *Orifice Sizes D through M (Metal Seats)*

Screw a standard bolt into the tapped hole (see table 7) in the face of the disc insert. Using hand force pull the bolt straight out. The disc insert with the retention clip (9) should come out with moderate force.

If the valve has been in dirty service it may be necessary to use a suitable solvent to aid in removal. If additional pullout force is required, a bolt with a T handle may be used. The method described below for Orifice sizes N through T may be used if necessary.

- *Orifice Sizes N through T (Metal Seats)*

Safety precautions should be followed whenever heavy parts are being lifted or transported. Dropping disc holder assembly may dislodge the insert.

The removal of the insert is accomplished by the use of a tool as shown in Figure 6. This tool consists of a rectangular steel bar which spans the outside diameter of the disc holder with a center hole through which the standard bolt can be inserted before screwing into the disc insert. A nut and washer is also required as shown. Tightening the nut with a wrench will exert a pulling force on the disc insert and cause it to be removed from the disc holder.

- *Orifice Sizes D through K (O-Ring Seats)*

The O-Ring seat design for Orifice sizes D through K has a retaining screw in the center of the disc insert. A drilled and tapped hole (4-40 UNC) is provided in the center of the retaining screw for removal of the disc insert (Figure 7). Screw a standard bolt into the hole in the retaining screw. Using hand force pull the bolt straight out. The disc insert with the retention spring should come out with moderate force.

- *Orifice Sizes L through T (O-Ring Seats)*

Safety precautions should be followed whenever heavy parts are being lifted or transported. Dropping the disc holder may dislodge the insert.

Remove the three retaining screws from the insert. Remove the retainer and O-ring seat. A tapped hole (refer to table 7) is provided in the disc insert for insertion of a removal bolt. Follow instructions for metal seated insert removal.

- l. For bellows valves only, place the disc holder in a vise (the larger sizes may require a 3-jaw vise) as shown in Figure 8. Using a suitable wrench unscrew the tailpiece and bellows from the disc holder.
- m. Remove the nozzle ring (3) from the nozzle (2).
- n. Remove the nozzle (2) from the valve body (1) if necessary. Unless the valve seat on the nozzle has been mechanically damaged or shows signs of corrosive attack, it will not be necessary to remove the nozzle. In most cases the nozzle can be reconditioned without removal from the valve body.
To remove the nozzle, turn the valve body over taking care not to damage the bonnet studs (21).
Turn the nozzle counterclockwise by using the wrench flats on the nozzle flange or a nozzle wrench designed to clamp onto the nozzle flange.

Cleaning

External parts such as the valve body, bonnet and cap should be cleaned by immersion in a bath such as hot Oakite solution or equivalent. These external parts may be cleaned by wire brushing, provided the brushes used do not damage nor contaminate the base metals. Only clean stainless steel brushes should be used on stainless steel components.

The internal parts such as the guide, disc holder, disc insert, nozzle ring and spindle should be cleaned by immersion in a commercial high alkaline detergent.

Guiding surfaces on the disc holder and guide may be polished using a fine emery cloth. The bellows and other metal parts may be cleaned using acetone or alcohol, then rinsed with clean tap water and dried.

Inspection

Check all valve parts for wear and corrosion. The valve seats on both the nozzle and disc insert must be examined to determine if they have been damaged. Most often, lapping the valve seats is all that is necessary to restore them to their original condition.

If the inspection shows that the valve seats are badly damaged, remachining will be necessary or it may be advisable to replace these parts. When the time element is a factor, it may be advantageous to replace damaged parts from spare parts stock, thereby permitting the replaced part to be checked and reworked at leisure. (See Figure 10 and Table 8 for critical dimensions.)

The valve spring (18) should be inspected for evidence of cracking, pitting or deformation.

The bellows (6B) in a Style AB/ABL valve should be inspected for evidence of cracking, pitting or deformation that might develop into a leak.

The bearing surfaces on the guide and disc holder should be checked for residual product build up and any evidence of scoring. Inspection of valve components is important to ensure proper valve performance. Damaged valve parts must be repaired or replaced.

Reconditioning of Valve Seats

The tightness of a valve and its proper operation depend directly on the condition of the seats.

Many pressure relief valve problems are due to eroded or damaged seats.

The standard Sempell Series "A" valve is constructed with a flat metal-to-metal seat. It is important that seating surfaces be properly refurbished by lapping with a flat cast iron lap coated with the correct lapping compound.

• Lapping Procedures

Unless the seats have been badly damaged by dirt or scale, lapping the seating surfaces should restore them to their original condition. Never lap the disc insert against the nozzle. Lap each part separately against a cast-iron lapping block of the proper size. These blocks hold the lapping compound in their surface pores and must be recharged frequently.

Lap the block against the seat. Never rotate the block continuously, but use an oscillating motion. Extreme care should be taken throughout to make certain that the seats are kept perfectly flat.

If considerable lapping is required, spread a thin coat of medium coarse lapping compound on the block. After lapping with the medium coarse compound, lap again with a medium-grade compound. Unless much lapping is called for, the first step can be omitted. Next, lap again using a fine grade compound. When all nicks and marks have disappeared remove all the compound from the block and seat. Apply polish compound to another block and lap the seat.

As the lapping nears completion only the compound left in the pores of the block should be present. This should give a very smooth finish. If scratches appear the cause is probably dirty lapping compound. These scratches should be removed by using compound free from foreign material.

Disc inserts should be lapped in the same way as nozzles. The disc insert must be removed from the holder before lapping. Before the disc insert is placed back in the holder all foreign material should be removed from both parts. The insert must be free when in the holder. If the disc insert is damaged too badly to be reconditioned by lapping, it should be replaced.

Remachining the insert will change critical dimensions, affect the action of the valve and is not recommended.






Figure 8



Lapping block resurfacing plate



Lapping block

Figure 9




Figure 10 - Nozzle seat critical dimensions

• **Lapping Blocks**

Lapping blocks are made of a special grade of annealed cast iron. There is a block for each orifice size. Each block has two perfectly flat working sides and it is essential that they retain this high degree of flatness to produce a truly flat seating surface on either the disc insert or the nozzle. Before a lapping block is used, it should be checked for flatness and reconditioned after use on a lapping plate. The block should be lapped in a figure eight motion, applying uniform pressure while rotating the lapping block against the plate as shown in Figure 9.

• **Lapping Compounds**

Experience has proven that medium coarse, medium fine, and polish lapping compounds will properly condition any damaged pressure relief valve seat except where the damage requires remachining. The following lapping compounds, or their commercial equivalents are suggested:

Grit Compound No.	Description
320	Medium Coarse
400	Medium
600	Fine
900	Polish

• **Machining of Nozzle Seats**

If machining of the nozzle seat or other major repairs are necessary it is recommended that the valve be returned to a Tyco Valves & Controls facility for repair. All parts must be accurately machined per SEMPELL specifications. No pressure relief valve will be tight, nor will it operate properly unless all parts are correctly machined. The most satisfactory way to machine a nozzle is to remove it from the valve body. However, it may also be machined while assembled within the valve body.

In any event it is vitally important that the seating surfaces run absolutely true before machining. Machining dimensions for SEMPELL Series "A" valves with metal-to-metal nozzle seats are shown in Figure 10 and Table 8. Remove only enough metal to restore the surface to its original condition. Turning to the smoothest possible finish will facilitate lapping.

The nozzle must be replaced when minimum face to seat dimension is reached. This critical dimension is shown in Table 8.

• **Machining of Disc Insert Seats**

When the damage to the disc insert seat is too severe to be removed by lapping, the disc insert may be machined and lapped provided that minimum seat height is maintained (Figure 11 and table 9).

Table 8 - Minimum nozzle face to seat dimensions (See Figure 10)

Orifice	Valve Type									
	12, 13, 14, 15, 16	22, 23, 24, 25, 26	32, 33, 34, 35, 36, 37	47	42, 43, 44, 45, 46	57	55, 56	65, 66, 67	75, 76, 77	
D	3,465	3,465	3,465	3,465	3,465	3,687	3,687	3,687	4,808	
E	3,465	3,465	3,465	3,465	3,465	3,687	3,687	3,687	4,808	
F	4,027	4,027	4,027	4,027	4,027	4,027	4,027	4,027	4,647	
G	3,777	3,777	3,777	3,777	3,777	3,777	3,777	4,777	4,777	
H	3,903	3,903	3,903	3,903	4,840	4,840	4,840	4,840	-	
J	4,340	4,340	4,340	4,340	5,121	5,121	6,455	6,455	-	
K	4,715	4,715	4,715	4,715	5,840	5,840	7,027	7,027	-	
L	5,059	5,059	5,277	5,277	5,277	6,250	6,250	6,250	-	
M	5,59	5,59	5,59	5,59	5,59	6,403	6,403	-	-	
N	6,121	6,121	6,121	6,121	6,121	-	-	-	-	
P	5,871	5,871	7,621	7,621	7,621	-	-	-	-	
Q	7,746	7,746	7,746	7,746	7,746	-	-	-	-	
R	8,121	8,121	8,121	8,121	8,121	-	-	-	-	
T	9,59	9,59	9,59	-	9,590 (*)	-	-	-	-	

* Type 42,43,44 not available

Table 9 - Disc insert minimum seat heights

Orifice	D & E	F	G	H	J	K	L	M	N	P	Q	R	T
"A"	0,332	0,370	0,369	0,398	0,429	0,531	0,546	0,605	0,632	0,692	0,783	0,781	0,839
"B"	0,021	0,025	0,030	0,036	0,044	0,051	0,063	0,070	0,076	0,091	0,118	0,139	0,176
	0,023	0,027	0,032	0,038	0,046	0,053	0,065	0,072	0,078	0,093	0,120	0,141	0,178

Assembly

All components should be clean. Before assembling the following parts, lubricate with pure nickel "Never-Seez".

- Nozzle and body threads
- Nozzle and body sealing surface
- All studs and nut threads
- Spindle and threads
- Set screw threads
- Spring washer bevels
- Adjusting bolt and bonnet threads
- Bonnet pipe plug
- Cap threads
- Dog shaft bearing threads
- Disc holder threads (bellows valves only)

Lubricate the spindle point thrust bearing and disc insert bearing with pure nickel "Never-Seez". Special attention should be given to the guiding surfaces, bearing surfaces and gasket surfaces to ensure that they are clean, undamaged and ready for assembly. (Figure 12)

For parts identification, refer to Figure 1.

- Before installing the nozzle (2) apply lubricant to the flange surface in contact with the valve body (1) and on the body to nozzle threads. Screw the nozzle (2) into the valve body (1) and tighten with a nozzle wrench.
- Screw the nozzle ring (3) onto the nozzle (2).

Note: The top of the nozzle ring should be above the nozzle seating surface. For P, Q, R and T Orifice Style ACL/ABL, position the nozzle ring per table 2.
- For bellows valves only, place the disc holder in a vise (larger sizes may require a 3 jaw vise) as shown in Figure 8. Install the tailpiece gasket (29).
Screw the bellows assembly onto the disc holder. Tighten with a suitable wrench.
- Assemble the disc insert (8) and the disc holder (5).
(See page 15 for O-ring soft seat assembly)
Install the disc insert retention clip (9) onto the disc insert.
Install the disc insert into the disc holder. The disc insert should snap into place using hand force only.
Safety precautions should be followed whenever heavy parts are being lifted or transported. Dropping disc holder assembly may dislodge the insert.
- Assemble the disc holder (5) and guide (15) by sliding the guide over the disc holder.

Note: The guide for D and E orifice valves protrudes up into the valve bonnet.
- Install the two guide gaskets (28), one above and one below the guide.

Note: When assembling bellows valves, the bellows flange eliminates the need for a bottom guide gasket.
- While holding the top of the disc holder, install the guide into the body. Align the hole of the guide with the body outlet. Once the guide is seated, the disc holder and disc insert can be lowered onto the nozzle.

Note: Lower the nozzle ring below the seats so that it moves freely.
- Place the spring (18) and washers (19) onto the spindle (16) and assemble the spindle to the disc holder (5) with the spindle cotter pins.

Note: No cotter pins are required in D through K orifice sizes all other orifice sizes use two cotter pins.
- Lower the bonnet (20) over the spindle and spring assembly onto the bonnet studs (21) in the body. Position the bonnet counter bore on the O.D. of the guide and lower the bonnet onto the guide.
- Screw the bonnet nuts (22) onto the bonnet studs and tighten down evenly to prevent unnecessary strain and possible misalignment.
- Screw the adjusting bolt (24) and nut (25) into the top of the bonnet to apply force on the spring. (The original set pressure can be approximated by screwing the adjusting bolt down to the predetermined measurement.)
- Move the nozzle ring up until it touches the disc holder, then lower it two notches. This is a test stand setting only.
- Place the set screw gasket (27) onto the set screw (4) and screw the set screw into the body engaging the nozzle ring. The nozzle ring should move back and forth slightly after the set screw is tightened.
- The valve is now ready for testing.

After testing, the following measures should be taken:

- Be sure that adjusting bolt nut (25) is locked.
- Return the nozzle ring to either the original recorded position or to the recommended position shown in Table 1.
- Install the cap or lifting device. See Figure 13 for lifting lever assembly.
- Seal the cap or lifting lever device and nozzle ring set screw to prevent tampering.




Figure 11 - Disc Insert Minimum Seat Height (Table 9)





Figure 12 - Recommended lubrication points

Figure 13
Cap and lifting levers



Assembly of Cap and Lifting Lever Devices

Series "A" pressure relief valves are furnished with several different caps and lifting lever devices. The following describes assembly of the available types of cap construction. (Disassembly is the reverse of assembly). For part identification refer to Figure 13.

- *Type B and K*

Install the cap gasket and screw the cap onto the top of the bonnet. Tighten the cap with a strap wrench. Install the cap plug gasket and screw cap plug into the cap. The test rod is installed only during system hydrostatic testing. Never install the test rod unless performing system hydrostatic testing.

- *Type C*

Screw the spindle nut onto the spindle.

Place the cap on the bonnet. Install the forked lever and forked lever pin. Attach the lever to the cap using the lever pin and secure with the lever pin cotter.

Adjust the spindle nut until the forked lever rests on the lever and there is a 1/16 inch minimum of play between the forked lever and the spindle nut. The spindle nut may be adjusted by removing the forked lever pin, forked lever and cap. When the spindle nut is in proper adjustment, install the spindle nut cotter pin. Replace the cap and forked lever and install the forked lever pin and forked lever pin cotter.

Position the lever opposite the valve outlet and install the four (4) cap set screws and tighten them against the groove in the top of the bonnet.

- *Type D*

Install the cap gasket on the bonnet. Screw the spindle nut onto the spindle. Place the dog in the cap and install the dog shaft so that the dog is horizontal and the square on the end of the dog shaft has a corner on top. With the dog shaft in the position above, scribe a horizontal line on the end of the dog shaft. This line must be horizontal when the lifting gear is finally installed on the valve. Install the dog shaft O-ring in the dog shaft bearing and place the dog shaft bearing gasket on the dog shaft bearing.

Screw the dog shaft bearing into the cap. Rotate the dog shaft so that the dog is pointing down and install the cap assembly onto the bonnet. Rotate the dog shaft so that the dog contacts the spindle nut. With the scribed line horizontal, remove the assembly and adjust the position of the spindle nut. Repeat the operation until the scribed line is horizontal when the dog contacts the spindle. Remove the assembly and install the spindle nut cotter pin.

Install the lifting gear assembly onto the bonnet and secure it with cap studs and nuts.

For Type D lifting levers that have two part caps (cap and cap top) the above procedure is more easily accomplished. After the cap is screwed to the bonnet, the positioning of the dog shaft is the same as above except that the positioning of the spindle nut is performed last through the open end of the cap.

With the dog in the horizontal position, screw the spindle nut onto the spindle until it contacts the dog. Install the spindle nut cotter, cap top gasket and screw the cap top into the cap.

- *Type E*

Assembly of Type E lifting lever is identical to Type D with the addition of the cap plug gasket and cap plug. The test rod is installed only during system hydrostatic testing. Never install the test rod unless performing system hydrostatic test.

- *Type H and M*

Assembly of Type H and M is identical to Type G and L with the addition of the cap plug gasket and cap plug. The test rod is installed only during system hydrostatic testing. Never install the test rod unless performing system hydrostatic test.

Soft Seat Construction

Coat O-ring with Parker Super O-Lube and place a small amount of Loctite 242 (or equivalent removable thread lock) onto retainer screw before assembly. Securely tighten retainer screw(s).

- *O-Ring Soft Seats*

Sempell Series "A" metal-to-metal seated pressure relief valves may be converted to an O-ring soft seat by replacing the standard disc insert and nozzle with those parts designed to house the O-ring soft seat or vice versa.

Figure 14




Table 10 - soft seat o-ring sizes

Orifice	O-ring size
D & E	2-013 All Elastomers 2-014 Teflon Only
F	2-113
G	2-116
H	2-120
J	2-125
K	2-130
L	2-226
M	2-228
N	2-230
P	2-337
Q	2-346
R	2-352
T	2-438

7. Style Variations

The Sempell Style Series "A" pressure relief valve was designed with flexibility and interchangeability in mind. Retrofitting from conventional to balanced bellows high performance liquid trim or soft seat design is accomplished with a minimum number of new parts. These style retrofits can be accomplished at lowest possible cost.

- *Balanced Bellows*

A Sempell AC conventional non-bellows pressure relief valve may be converted to a Style AB balanced bellows valve simply by adding the bellows assembly and tailpiece gasket.

- *ACL/ABL Liquid Trim*

Sempell AC/AB pressure relief valves in D to N orifice sizes may be converted to high performance ACL/ABL liquid service design simply by replacing the standard disc holder with a ACL/ABL disc holder, or vice versa. For P to T orifice sizes a new nozzle ring is also required.

- *O-Ring Soft Seat Design*

Sempell Series "A" pressure relief valves in all orifice sizes may be converted from the standard metal-to-metal seats to an exceptionally tight soft seat design. This style conversion can be accomplished by replacing the standard disc insert and nozzle with parts adapted to accommodate the soft seat design.

The Sempell soft seat design uses standard size O-rings and is capable of handling pressures to 1480 PSIG. Standard O-ring materials include Buna N, EPR, Viton, Kalrez, Silicone and Teflon. (See Figure 14 and Table 10).

8. Service Records

Service records should be completed before a valve is returned to service. These records are important and will provide guidance on establishing time intervals between repairs as well as providing the historical record of repairs and service conditions. Well kept records will be useful in predicting when to retire a valve and which spare parts should be maintained in inventory to ensure uninterrupted plant operation.

9. Spare Parts

When ordering spare parts, the valve serial number should be given together with set pressure, part name and item number, valve size and style. On the valve nameplate the valve serial number is shown.

Spare parts may be ordered from any Tyco Valves & Controls Regional Sales Office or Representative.

10. Trouble Shooting Pressure Relief Valves

Troubles encountered with pressure relief valves can vitally affect the life and performance of the valve and must be corrected at the first possible opportunity.

Failure of a pressure relief valve to function properly could result in the rupture of a line or vessel jeopardizing the safety of personnel and causing damage to property and equipment. Some of the most common troubles and the recommended correction measures are discussed in the following paragraphs.

Seat Leakage

Of all the problems encountered with pressure relief valves, seat leakage is the most common and the most detrimental. A leaking valve allows fluids to circulate into the secondary pressure zone of the valve where it can cause corrosion of the guide and valve spring.

When a leaking valve problem is not immediately addressed, the leakage itself will further contribute to seat damage through erosion (wire-drawing).

- *Seats Damaged by Foreign Matter*

Seating surfaces may be damaged when hard foreign particles such as mill scale, welding spatter, coke and dirt are trapped between the seats. While this type of damage usually occurs while the valve is in service, it may also happen in the maintenance shop.

Every precaution should be taken to clean the process system before installing a pressure relief valve and to test the valve using only clean fluids.

Damaged seating surfaces are generally reconditioned by lapping. Most often small pits and scratches may be removed by lapping alone. More extensive damage will also require remachining prior to lapping.

In some instances valve construction can be changed to reduce the effects of seat leakage. The use of an O-ring soft seat when applicable will minimize leakage and thus eliminate the associated corrosion and erosion problems. If it is not possible to use a soft seated valve, or if the corrosive media is present in the exhaust system, conversion to a Style AB/ABL bellows seated valve will isolate and protect the guides and valve spring from any corrosive fluids.

- *Distortion from Piping Strains*

Valve bodies can be distorted by excessive piping loads causing seat leakage. Both inlet and discharge piping must be properly supported and anchored so that high bending loads are not transmitted to the valve body.

- *Operating Pressure Too Close to Set Pressure*

A carefully lapped metal-to-metal seated valve will be commercially tight at a pressure approximately ten percent under the set pressure or 5 PSI, whichever is greater. Consequently, this minimum pressure differential should be maintained between set and operating pressure to avoid seat leakage problems.

- *Chatter*

Oversized valves, excessive pressure drop in the inlet lines, restrictions in the inlet line, too great a build up of back pressure or pulsating inlet pressure will cause instability to the pressure relief valve. In such installations, the pressure under the valve disc may be great enough to cause the valve to open, but as soon as flow is established, the pressure drops allowing the valve to immediately close. This cycle of opening and closing sometimes occurs at very high frequency causing severe seat damage, sometimes beyond repair.

Proper valve selection and installation techniques are paramount to reliable valve performance.

- *Incorrectly Adjusting Lifting Gear*

A space of 1/16 inch minimum should always be provided between the lifting device and the spindle lift nut. Failure to provide sufficient clearance may result in inadvertent contact causing a slight shift in the opening pressure.

- *Other Causes of Seat Leakage*

Improper alignment of the spindle, too much clearance between the valve spring and the spring washers, or improper bearing contact between the adjusting bolt and the spring washers, spindle and disc holder or spindle and lower spring washer may cause seat leakage problems. Spindles should be checked for straightness and springs and spring washers should be properly fitted and kept together as a spring assembly.

- *Corrosion*

Corrosion may result in pitting of valve parts, failure of various valve parts, build up of corrosive products and general deterioration of the valve materials.

Corrosive attack is generally controlled through selection of suitable materials or by employing a bellows seal to isolate the valve spring, adjusting bolt, spindle and guiding surfaces from the corrosive attack of the process fluid.

Environmental corrosion attacks all exposed surfaces, including studs and nuts. In general, the materials required for a particular service are dictated by the temperature, pressure and the degree of corrosion resistance required.

